

SET		Pager / FRS / CLP / Remocon			
Assembly					
kHz Filter	450~455 kHz	●	●	●	
kHz Resonator	375~1250 kHz				●
MHz Resonator - Pin Type - SMD Type 2520, 3731, 7234 Size	3~6 MHz				●
	6~14 MHz				
	14~50 MHz				
FM Filter	10, 7 MHz	●			●
kHz Discriminator	450~455 kHz	●	●		

SET		PC SET			
Assembly					
kHz Filter	450~455 kHz				
kHz Resonator	375~1250 kHz				
MHz Resonator - Pin Type - SMD Type 2520, 3731, 7234 Size	3~6 MHz	●		●	
	6~14 MHz				●
	14~50 MHz		●	●	●
FM Filter	10, 7 MHz	●			
kHz Discriminator	450~455 kHz				

SET		Printer
Assembly		
kHz Filter	450~455 kHz	
kHz Resonator	375~1250 kHz	
MHz Resonator - Pin Type - SMD Type 2520,3731,7234 Size	3~6 MHz	●
	6~14 MHz	●
	14~50 MHz	●
FM Filter	10,7 MHz	●
kHz Discriminator	450~455 kHz	

SET		DVD	
Assembly			
kHz Filter	450~455 kHz		
kHz Resonator	375~1250 kHz		
MHz Resonator - Pin Type - SMD Type 2520,3731,7234 Size	3~6 MHz		
	6~14 MHz	●	
	14~50 MHz		●
FM Filter	10,7 MHz		
kHz Discriminator	450~455 kHz		

SET		Digital TV
Assembly		 Digital TV
kHz Filter	450~455 kHz	
kHz Resonator	375~1250 kHz	
MHz Resonator - Pin Type - SMD Type 2520,3731,7234 Size	3~6 MHz	
	6~14 MHz	
	14~50 MHz	
FM Filter	10,7 MHz	
kHz Discriminator	450~455 kHz	

SET		Mobile Communication	
Assembly		 Cellular MP Player PDA Digital Camera Wireless Headset	
kHz Filter	450~455 kHz		
kHz Resonator	375~1250 kHz		
MHz Resonator - Pin Type - SMD Type 2520,3731,7234 Size	3~6 MHz		
	6~14 MHz		
	14~50 MHz		
FM Filter	10,7 MHz		
kHz Discriminator	450~455 kHz		