



To use the SPI interface, pull up the SEN pin.
Otherwise pull down the SEN.

Title			W5100 Reference schematic
Size	Document Number	Rev	1.0
B	<Doc>		
Date:	Wednesday, December 20, 2012	of	1